

AW189446-01-09_29_2004

SCB-68 Quick Reference Label

671X / 672X / 673X DEVICES



PIN # SIGNAL

68	NC
34	AO GND
67	AO GND
33	NC
66	AO GND
32	AO GND
65	AO 7
31	AO GND
64	AO GND
30	AO 6
63	AO GND
29	AO GND
62	NC
28	AO 5
61	AO GND
27	AO GND
60	AO 4
26	AO GND
59	AO GND
25	AO 3
58	AO GND
24	AO GND
57	AO 2
23	AO GND

PIN # SIGNAL

12	D GND
46	NC
13	D GND
47	P0.3
14	+5 V
48	P0.7
15	D GND
49	P0.2
16	P0.6
50	D GND
17	P0.1
51	P0.5
18	D GND
52	P0.0
19	P0.4
53	D GND
20	AO EXT REF
54	AO GND
21	AO 1
55	AO GND
22	AO 0
56	AO GND

PIN # SIGNAL

1	FREQ OUT
35	D GND
2	CTR 0 OUT
36	D GND
3	PFI 9/CTR 0 GATE
37	PFI 8/CTR 0 SOURCE
4	D GND
38	PFI 7
5	PFI 6/AO START TRIG
39	D GND
6	PFI 5/AO SAMP CLK
40	CTR 1 OUT
7	D GND
41	PFI 4/CTR 1 GATE
8	+5 V
42	PFI 3/CTR 1 SOURCE
9	D GND
43	PFI 2
10	PFI 1
44	D GND
11	PFI 0
45	EXT STROBE

P/N 189446B-01

Factory Default Setting

S5 S4 S3 S1 S2

ACCEPTED

By: _____